## 3.4 **STOPPING PLUGS T series**

Male stopping plugs of all kind of threads, suitable for enclosure entries

T = tstopping plugs

Stopping plugs type **T xa** x = M thread type

a = M thread size







